


	DESCRIPTION	OEM PART NUMBER	Image
1.	Grid Resistor .927 Ohms	E8304194, E40085144	
2.	Grid Resistor .860 Ohms	E8304193, E40085145	
3.	Grid Resistor .922 Ohms	E8347464, E40085146	
4.	Grid Resistor 1.072 Ohms	E8339532	
5.	Grid Resistor .970 Ohms	E8339533	
6.	Grid Resistor .642 Ohms	E9337613	
7.	Grid Resistor .689 Ohms	E9337614	
8.	Grid Resistor .923 Ohms	E9331050, E9191050	
9.	Grid Resistor .860 Ohms	E9331051	
10.	Grid Resistor .660 Ohms	E8185703, E40085141	
11.	Grid Resistor .690 Ohms	E8185705, E40085143	
12.	Grid Resistor .660 Ohms	E8185704, E40085142	
13.	Grid Resistor .690 Ohms	E8190834	
14.	Grid Resistor .860 Ohms	E40010556	
15.	Grid Resistor .860 Ohms	E40010557	
16.	Grid Resistor .965 Ohms	E40010558	
17.	Grid Resistor .632 Ohms	E40010559	
18.	Grid Resistor .766 Ohm	E40010560	
19.	10Kw Aux Gen	E8405875	
20.	14Kw Aux Gen	E8405875MOD	
21.	18Kw DC Aux Gen	E8122750	
22.	18Kw AC Aux Gen	E4979844	
23.	18Kw AC Aux Gen	E9551383	
24.	18Kw AC Aux Gen	E9533149	

25.	24Kw AC Aux Gen	E3195473	
26.	Main Generator	D12	
27.	Main Generator	D15	
28.	Main Generator	D22	
29.	Main Generator	D32B & D32P	
30.	Main Generator	D32E & D32E1	
31.	Main Alternator	AR10	
32.	Main Alternator	AR11	
33.	Main Alternator	AR15 - AR17	
34.	Main Alternator	AR20	
35.	Auxiliary Generator	GY27L2	
36.	Auxiliary Generator	GY27M2	
37.	Auxiliary Generator	581	
38.	Auxiliary Generator	586	
39.	Auxiliary Generator	598	
40.	Main Alternator	GTA9	
41.	Main Alternator	GTA11	
42.	Main Alternator	GTA15	
43.	Main Alternator	GTA16	
44.	Insulating Diode Boot	E40048214	
45.	Diode Negative	E40029131 AR10	
46.	Diode Positive	E40029132 AR10 AR11	
47.	Diode Positive	E40032602 AR20	
48.	Diode Positive	E40053999	
49.	Diode Negative	E40032602	
50.	Transformer	E8374003 AR10	
51.	Transformer	E9561605 AR11	
52.	Resistor AR10 50W 5 OHMS	E8380922	
53.	Resistor 400W 3.75 OHM	E8429166	

E8400143



54.	Contact Control Cabinet		
55.	Contact Gen. Shunt Field	E8251126	
56.	Contact Power	E8192805	
57.	Contact Power	E8458534	
58.	Contact Magnetic	E8461331	
59.	Motor Module Control	E8453175	
60.	Motor Module Control	E8463776	
61.	Controller Non Dynamic	E9091052	
62.	Controller Dynamic & Brake	E9093629	
63.	Controller Dynamic & Brake	E9325903	
64.	Voltage Regulator 3 Terminal	E8330790	
65.	Voltage Regulator 4 Terminal	E8351980	
66.	6 Panel Light Enhancement	E8484375	
67.	Rheostat 1500 Ohms Linear	E9322456	
68.	SGC 5000A Power Contactor	E40040084	
69.	Reverser 4 motor 4 Contact	E8131665	
70.	Reverser 2 Motor 2 Contact	E8131666	
71.	Aux and Other Modular Panels	G17FL & G17FM	
72.	2a SINGLE POLE	E8458705	
73.	5a SINGLE POLE	E8456915	
74.	10a SINGLE POLE	E8458697	
75.	15a SINGLE POLE	E8458698	
76.	30a SINGLE POLE	E8458699	
77.	3a DOUBLE POLE	E8458735	
78.	5a DOUBLE POLE	E8458728	
79.	5a DOUBLE POLE	E8458736	
80.	15a DOUBLE POLE	E8458739	
81.	15a DOUBLE POLE	E9090434	
82.	15a DOUBLE POLE	E8458727	
83.	30a DOUBLE POLE	E8458724	
84.	35a DOUBLE POLE	E8458726	
85.	40a DOUBLE POLE	E8458738	

E8414231

86.	50a DOUBLE POLE		
87.	50a DOUBLE POLE	E8448859	
88.	50a DOUBLE POLE	E8316879	

89.	60a DOUBLE POLE	E8433382	
90.	60a DOUBLE POLE	E8485669	
		E6945270	
91.	70a DOUBLE POLE		
92.	100a DOUBLE POLE	E8433383	
93.	150a DOUBLE POLE	E8433381	
94.	15a TRIPLE POLE	E8458741	
95.	30a TRIPLE POLE	E8458742	
96.	15a SINGLE POLE	G41A218545P4	
		G41B544907P1	
97.	15a SINGLE POLE		
	25a DOUBLE POLE		
98.		G41B544907P2	
99.	15a DOUBLE POLE	G41A212414P14	
100.	30a DOUBLE POLE	G41A212414P2	