



	DESCRIPTION	OEM PART NUMBER
1.	INTERLOCK 1NO-1NC	10-6817-4
2.	SPACER	115X2594
3.	SPACER, Phénolique	11D786P1
4.	INTERLOCK	17AF14H29
5.	INTERLOCK	17AF21F26
6.	CONTACTOR	17CM53A14
7.	CONTACTOR	17CM53AA9
8.	CONTACTOR	17CM53B11A
9.	CONTACTOR	17CM53B3
10.	CONTACTOR	17CM53B5
11.	CONTACTOR	17CM53B7
12.	CONTACTOR	17CM53K7
13.	CONTACTOR	17CM53Y9
14.	CONTACTOR	17CM55A5
15.	CONTACTOR	17CM55N10
16.	CONTACTOR	17CM55R6
17.	CONTACTOR	17CM55S6
18.	CONTACTOR- WITHOUT COIL	17CM55Y3 SPECIAL
19.	PANEL	176A7157G1
20.	INTERLOCK	17AF14J9
21.	INTERLOCK	17AF14K18
22.	INTERLOCK	17AF20B15S
23.	INTERLOCK	17AF20B5S
24.	INTERLOCK	17AF21F32
25.	INTERLOCK	17AF41L2
26.	POSITION SENSOR	17AF45C3
27.	CONTACTOR	17CM53B10
28.	CONTACTOR	17CM53K11A
29.	CONTACTOR	17CM53S17

30.	CONTACTOR	17CM55AD5A
31.	CONTACTOR	17CM55AH6
32.	CONTACTOR	17CM55AJ11B
33.	CONTACTOR	17CM55AR5, 17CM55S5
34.	CONTACTOR	17CM55N3
35.	CONTACTOR	17CM57A6
36.	CONTACTOR	17CP2BC11
37.	FIXED CONTACT ASSM	130050-3
38.	PANEL,GE 482A516G1	152A7243G1
39.	INTERLOCK	17AD1A2
40.	INTERLOCK	17AF14H3
41.	INTERLOCK	17AF14J3
42.	INTERLOCK	17AF14S18
43.	INTERLOCK	17AF20B25S
44.	INTERLOCK	17AF21A25
45.	INTERLOCK	17AF21F14
46.	INTERLOCK	17AF41B1
47.	INTERLOCK	17AF41M1
48.	BOARD, Terminal	17BC17A1
49.	BOARD, Terminal	17BC17B1
50.	BOARD, Terminal	17BC17C1
51.	CONTACTOR	17CM53K9
52.	CONTACTOR	17CM53Y7
53.	CONTACTOR	17CM55A5A
54.	CONTACTOR	17CM57A12A
55.	SWITCH HAZARD UNIT	10635900
56.	INTERLOCK	17AF14H1
57.	INTERLOCK	17AF14H2
58.	INTERLOCK	17AF14H25
59.	INTERLOCK	17AF14H7
60.	INTERLOCK	17AF14J7
61.	INTERLOCK	17AF14K1
62.	INTERLOCK	17AF20B20
63.	INTERLOCK	17AF20B26S
64.	INTERLOCK	17AF20B50S
65.	INTERLOCK	17AF20B7
66.	INTERLOCK	17AF41L1
67.	POSITION SENSOR	17AF45C2

68.	CONTACTOR	17CM53A10
69.	CONTACTOR	17CM53AF18
70.	CONTACTOR	17CM53E10A
71.	CONTACTOR	17CM53E11A
72.	CONTACTOR	17CM55J3
73.	DB CONTACTOR GE	17CM55L3
74.	CONTACTOR	17CM57A9
75.	CONTACTOR	17CM57A9A
76.	CONTACTOR	17CM57B15
77.	CONTACTOR C1	17CM57B2
78.	CONTACTOR	17CM57B3
79.	CONTACTOR	17CM57B6
80.	CONTACTOR	17CM57D7
81.	CONTACTOR	17CM57R5
82.	CARD BN	17FC114H4
83.	PANEL	17FM203D1
84.	PANEL	17FR47A4
85.	PANEL	17FR53B1
86.	RELAY	17LV59N13
87.	RELAY	17LV59N13B
88.	RELAY	17LV66A37A
89.	RELAY	17LV66AA37A
90.	RELAY	17LV66AM48
91.	RELAY	17LV66BD51
92.	RELAY	17LV66CY53
93.	RELAY	17LV66DA46
94.	RELAY	17LV66J1
95.	RELAY	17LV66J15
96.	RELAY	17LV66J23
97.	RELAY	17LV66J46
98.	RELAY	17LV68E2
99.	MAGNET VALVE	17MV36B2
100.	MAGNET VALVE	17MV38G8
101.	VALVE STEM SS BY 187V772P1	187V772P1
102.	COIL 290 Ohms	2738573G2
103.	ARC CHUTE	2744700G2
104.	INTERLOCK 2NO	3X6662
105.	DB CONTACTOR GE	17CM55L6

106.	CONTACTOR	17CM55Y3
107.	CONTACTOR	17CM57A15
108.	CONTACTOR	17CM57J5
109.	PANEL	17FM203C2
110.	RELAY	17LC38A1A
111.	RELAY	17LV40F25
112.	RELAY	17LV59N13C
113.	RELAY	17LV66AB19
114.	RELAY	17LV66AD22
115.	RELAY	17LV66AV1
116.	RELAY	17LV66AV26
117.	RELAY	17LV66BA20A
118.	RELAY	17LV66BT49
119.	RELAY	17LV66BY20
120.	RELAY	17LV66C20
121.	RELAY	17LV66CK46
122.	RELAY	17LV66DT55
123.	RELAY	17LV66J13
124.	RELAY	17LV67D3
125.	RELAY	17LV67D5
126.	RELAY	17LV68E7
127.	MAGNET VALVE	17ME1A24
128.	MAGNET VALVE	17MV38G12
129.	MAGNET VALVE	17MV38J12
130.	VALVE	17MV39C2
131.	RELAY	17LC38A1
132.	RELAY	17LV66AC20
133.	RELAY	17LV66BD1
134.	RELAY	17LV66DW10
135.	RELAY	17LV66E2
136.	RELAY	17LV66ED10
137.	RELAY	17LV66J10
138.	RELAY	17LV67F9
139.	MAGNET VALVE	17MV23A4
140.	COIL 317 / 338 OHMS	3121620G1
141.	SUPPORT, Stationary contact,	332B492P1
142.	RELAY 3NO 3NC	40001246
143.	CONTACTOR	40010561-24VDC

144.	VOLTAGE REGULATOR	40048361
145.	SNUBBER	41A244100AAP3
146.	SNUBBER	41A244100AAP5
147.	SNUBBER	41A244100AAP6
148.	COIL RESET 13.9 Ohms	41A250370G1
149.	COIL ASSY 17LV59	41A259011G1
150.	SPACER, STATIONARY CONTACT 1.4	41A262072P5
151.	POTENTIOMETER	41A296308AFP1
152.	GROUND CABLE	41B537416G5
153.	SHROUD, Throttle - Assy.	41B562159G1
154.	INTERLOCK	41C650900G1
155.	CONTACTOR INCLUDING INTERLOCK	41C651678G4
156.	CONTACTOR	17CM57B7
157.	CONTACTOR	17CM57B9
158.	CONTACTOR	17CM57D6
159.	CONTACTOR	17CM57M15
160.	CONTACTOR	17CM57W18A
161.	CONTACTOR	17CP2BC3
162.	CARD BX	17FC115K1
163.	VOLTAGE REGULATOR	17FH20B2
164.	PANEL	17FR57A3
165.	RELAY	17LV59N13D
166.	RELAY	17LV66AA19
167.	RELAY	17LV66AM33
168.	RELAY	17LV66AT33A
169.	RELAY	17LV66BD10
170.	RELAY	17LV66BD52
171.	RELAY	17LV66BT4
172.	RELAY	17LV66DD7J
173.	RELAY	17LV66EC10J
174.	RELAY	17LV66F4
175.	RELAY	17LV66J22B
176.	RELAY	17LV66J24A
177.	RELAY	17LV66S40
178.	RELAY	17LV66S48
179.	MAGNET VALVE (SPECIAL)	17MV38J6
180.	MAGNET VALVE	17MV40C1
181.	CONTACT KIT	40001025

182.	CONTACTOR EPC EMD	40042183
183.	COIL 0.68 OHMS, Ground relay	40057272
184.	RELAY 3NO 3NC DELAY	40083475
185.	SNUBBER	41A244100AAP2
186.	BOARD, ASM, TERMINAL REV.F	41A250095G10
187.	COIL 231 ohms	41A250376G1
188.	RELAY BC	41A251636P1
189.	INSULATOR TUBE, 2.227" long	41A251641P23
190.	BUSHING, Supporting	41A264535P3
191.	SHIM, frame to base, 0.032 TH	41A272792P1
192.	KIT A/C FAN	41A302690G1
193.	ARMATURE with stop block	41B551021G4
194.	INSULATION ASSY - ARC CHUTE	41B551056G4
195.	FRAME HEAD	41C630228P1
196.	FRAME HEAD	41C630228P2
197.	BUS RING KIT	41C632091G4
198.	CONTACTOR INCLUDING INTERLOCK	41C651678G23
199.	SUPPORT ASSEMBLY	41C651701G2
200.	CONTACTOR WITH INTERLOCK	41C662781G12
201.	CONTACTOR - battery	41C662781G4
202.	CONTACTOR WITH INTERLOCK	41C662781G6
203.	CONTACTOR WITH INTERLOCK	41C662786G6
204.	CONTACTOR PLUS INTERLOCK	41C663321G2
205.	INSULATOR KIT - COMMUTATOR END	1851632
206.	MAGNET CORE	187V673
207.	COIL 732 / 775 OHMS	3122101G1
208.	MAGNET FRAME	336B636P1
209.	ARM with bushing assembly	341B592G8
210.	KIT ARC CHUTE	40004013
211.	CONTACTOR	40010561
212.	POCHETTE DE JOINT	40014455
213.	CONTACT KIT	40015677
214.	CONTACTOR	40020570
215.	GROUND RELAY	40050359
216.	SUPPRESSOR KIT	40058970
217.	CONTACTOR	40114986
218.	COIL 73 Ohms	41A250340G1
219.	MODULE SUPPRESION	41A264833G1

220.	POWER TRANSFORMER 16 KW	41A296320BNP2
221.	ARC CHUTE	41B550409G1
222.	BLOCK OPERATOR 17CP2	41B564967P1
223.	ARCING HORN	41B566373G1
224.	COIL 59.6 Ohms	41B566575P1
225.	ARC CHUTE	41C650088G2
226.	CONTACTOR ASSY	41C663321G4
227.	CONTACTOR	41C663322G2
228.	ARC HORN	41D756439G1
229.	ARC CHUTE	426C844G2
230.	SIDE, ARC CHUTE	426C848P2
231.	SLEEVE for screw #10 (2.230")	4710386P1
232.	ARC CHUTE	2744700G8
233.	INTERLOCK 2NC	3X6663
234.	CIRCUIT BOARD ASSY	40007929
235.	SNUBBER	41A244100AAP13
236.	SNUBBER	41A244100AAP4
237.	SPACER- 5 1/8"	41A251932P1
238.	CONTACTOR	41A324267P3
239.	ARC HORN ASSY	41B554412G1
240.	DIODE ASSY	41B565428G1
241.	COIL 7 Ohms	41B566108P1
242.	CONTACTOR INCLUDING INTERLOCK	41C651678G22
243.	CONTACTOR	41C651678G30
244.	ARC CHUTE assy	41C655653G1
245.	TRACTION ALT. CRANK. CONTACTOR	41C662780G4
246.	CONTACTOR WITH INTERLOCK	41C662781G15
247.	CONTACTOR PLUS INTERLOCK	41C663321G3
248.	BUS RING KIT	41D730693G6
249.	CHUTE, Arc (molded type)	41D750051G1
250.	ARC CHUTE	41D750063G3
251.	ARC CHUTE	41D756445G1
252.	CORE, blowout coil	4710381P1
253.	MOVABLE CONTACT ASSY	4735720G1
254.	COIL 117 Ohms	4739356G1
255.	COIL 6.4 ohms	4739364G1
256.	COIL 27.5 Ohms	4739365G1
257.	COIL 365 OHMS	4739367G1

258.	SUPPORT, Stationary Contact	4767491P1
259.	SPRING & NUT	482A486G1
260.	POLE PIECE SUPPORT LEFT HAND	482A583G6
261.	SHIELD, pole piece 1/16 TH.	4710809P1
262.	COIL 145 / 153 Ohms	4739369G2
263.	COIL 2870 Ohms	4739380G2
264.	SIDE - ARC CHUTE	4746672P8
265.	SUPPORT AVEC BRACKET	488A181G1
266.	FINGER WITH TIPS	492A199G1
267.	CONTACT	496A428G1
268.	SUPRESSOR VALVE	558479
269.	CONTACT FINGER	6700284G1
270.	CONTACT FINGER	6700393G2
271.	CONTACT FINGER	6700398G2
272.	POST, CONTACT BLOC	6715967P1
273.	PIN, RESET ARMATURE HINGE	6721901ABP20
274.	INTERLOCK	6735511G1
275.	COIL MAGNET 542 OHMS	8136458
276.	COVER HEAD	8137189
277.	RELAY	8157086
278.	SHUNT, CLOCK SPRING	8175459
279.	DIAPHRAGM ASSEMBLY, Silastic	8179299
280.	CONTACTOR	8184973
281.	COIL MAGNET 386 Ohms	8208912
282.	CARRIER MOVABLE CONTACT	8208924
283.	BASE ASSY. UPPER CONTACT	8209955
284.	COIL 23.35 Ohms	8209966
285.	INNER BEARING COVER PE	8235357
286.	COVER ASSY	8236101
287.	ARC CHUTE	41D750051G3
288.	BASE	41D754144P1
289.	VALVE BODY WITH VALVE AN	426C207G3
290.	SPACER, insulation	4710385P1
291.	COIL 818 Ohms	4739157G1
292.	COIL 48.8 Ohms	4739318G1
293.	COIL 1415 OHMS	4739368G1
294.	COIL 182 Ohms	4739477G2
295.	COIL 9250 OHMS	4739488G1



296.	POLE PIECE SUPPORT RIGHT HAND	482A583G5
297.	SHUNT	492A200G3
298.	VALVE SEAT	558490
299.	CONTACT FINGER WITH COMPRESSIO	6700314G1
300.	MOVABLE CONTACT WITH OPER. ARM	6702372
301.	CONTACT	6706024G1
302.	HORN	6711757G1
303.	INSULATION SHIELD	6712046P1
304.	COIL 700 Ohms	8113756
305.	WHEEL SLIP RELAY	8124362
306.	CONNECTOR	8160270
307.	WHEEL SLIP RELAY	8172591
308.	WHEEL SLIP RELAY	8191734
309.	RELAY BC	8204396
310.	COIL MAGNET 495 Ohms	8208928
311.	CHUTE ARC	8208933
312.	WHEEL SLIP RELAY	8232206
313.	RHEOSTAT 80 OHMS 50W	8237523
314.	RELAY BC	8250370
315.	CONTACTOR, Shunt field	8254055-BUS
316.	CONTACT TIP	482A768G1
317.	SHUNT	492A200G1
318.	SPACER	492A476P2
319.	CONTACT	496A427G1
320.	VALVE	560421
321.	MOUNTING PLATE	6700603
322.	CONTACT	6700890G1
323.	CONTACT ARM	6701850G1
324.	SPACER	6713726P1
325.	SUPPORT	6715974P1
326.	BLOCK	6716316G2
327.	SLIP RING ASSY	6734911P5
328.	CONTACT	8112684
329.	COIL 200 OHMS	8152565
330.	COIL 590 ohms	8190640
331.	WHEEL SLIP RELAY	8209167
332.	PLUNGER ASSY MAGNET W/ CARRIER	8209957
333.	COVER ASSY RELAY WITH WINDOW	8209960

334.	CARRIER ASSY Movable contact	8209968
335.	TIP, Movable contact	8219528
336.	BEARING HOUSING ASSY	8235218
337.	COVER ASSY	8235994
338.	CONTACTOR, Bat. field	8254056-BUS
339.	CONTACT, Stationary Double tip	8260106
340.	BASE ASSY, Upper contact	8261217
341.	CONTACTOR, Shunt field	8254055
342.	CONTACT	8260104
343.	COIL 36 Ohms-24 VDC	8261147-24 VDC
344.	PLATE, BACK COVER	8261151
345.	PLATE, FRONT COVER	8261152
346.	KIT CONTACTOR, STARTING AUX.	8261221-ASK
347.	TIMER UNIT, Pneumatic	8286865 CONFIG A
348.	COIL MAGNET 745 Ohms 74 VDC	8291717
349.	CONTACTOR, BAT. FIELD	8294080
350.	PLUNGER ASSY, Magnet	8310914
351.	RESISTOR 25 OHMS 25W	8318101
352.	CONTACTOR, BFA, GF	8330937
353.	RHEOSTAT	8331127
354.	RELAY BC	8331302
355.	CONTACTOR, BFA, GF	8332661
356.	COIL Magnet 19.8 Ohms	8339342
357.	CONTACTOR, Motor field shuntin	8340028
358.	CONTACTOR, Bat. field	8342427
359.	RELAY BC	8346622
360.	BASE ASSY, Upper contact	8347354
361.	CONTACTOR	8351006
362.	RHEOSTAT	8354134
363.	CONTACTOR W/INTERLOCK 17AF41M1	41C652177G21
364.	ARC CHUTE	41C652535G6
365.	SPACER, 2 3/16" LONG	41C653393P7
366.	CONTACTOR Xfc W/ INTERLOCK	41C662780G3
367.	CONTACTOR with interlock	41C662781G5
368.	CONTACTOR ASSY	41C663321G7
369.	ARC CHUTE	41C667662G1
370.	ARC CHUTE	41D750063G1
371.	ARC CHUTE	41D752109G1

372.	ARC CHUTE	41D758311G1
373.	COIL 25.2 OHMS	4739382G2
374.	HORN with spring, arcing	488A478G1
375.	ARM	492A201G2
376.	CONTACT SUPPORT	496A428G2
377.	PIN INCLUDED RETAINING RING	558469
378.	DOG CAM ASSY	559268
379.	BRAKE VALVE WITH INDEP.	564315-SIM
380.	CONTACT FINGER	6700391G2
381.	CONTACT, operating arm and con	6701849
382.	MOVABLE CONTACT	6701998G1
383.	ADJUSTING SCREW 10-32 x 2-7/16	6706033G1
384.	TUBE - PHENOLIC 23/32 LONG	6712696P1
385.	CAM BLOCK ASSY (17AF21F26)	6743746P5
386.	CONTACTOR	77019956
387.	FUSE HOLDER	8004542
388.	LOAD REGULATOR	8117013
389.	CONTACT ASSY, Movable bridge	8136447
390.	CARRIER ASSY Movable interlock	8266413
391.	CONTACT STAT 4-1/4 x 3 x 2-1/4	8269681
392.	TIME DELAY RELAY	8272600
393.	RELAY, Time delay	8276599
394.	COMMUTATOR - LOAD REGULATOR	8277228
395.	COIL MAGNET 145 OHMS	8278698
396.	SWITCH-KNIFE	8280178
397.	FUSE HOLDER	8280180
398.	SWITCH, KNIFE	8280185
399.	CONTACTOR, BFA	8302169
400.	CARRIER ASSY Movable interlock	8313805
401.	RELAY BC	8327263
402.	RELAY BC	8334954
403.	CONTACT ASSY MOVABLE ARCING	8337574
404.	CONTACTOR, FS	8345137
405.	RHEOSTAT	8354311
406.	GENERAL PURPOSE RELAY	8357416
407.	RELAY	8357418
408.	RELAY	8357419
409.	RESISTOR 8 OHMS 25W ASSY	8357919

410.	CONTACTOR, Bat. field	8254056
411.	PLATE, Back cover	8258609
412.	BASE ASSY, Lower contact	8261138
413.	BASE ASSY, Upper contact	8261141
414.	CARRIER ASSY Movable interlock	8261144
415.	COIL Magnet 360 Ohms	8261147
416.	BLOCK ASSY Movable contact 30A	8261221
417.	CONTACTOR, Bat. field	8262004
418.	RELAY BC	8264546
419.	CHUTE ASSY. ARC	8274223
420.	SWITCH ASSY, Includes	8276568
421.	RELAY, Time delay	8276597
422.	RELAY, Time delay	8276598
423.	RELAY BC	8308051
424.	PLATE, Barrier	8310774
425.	CARRIER ASSEMBLY, Post & plate	8326499
426.	SWITCH, Traction motor cut-out	8330045
427.	CONTACTOR	8330085
428.	INTERLOCK ASSY	8336118
429.	CONTACT ASSY	8337579
430.	CONTACT ASSEMBLY STATIONARY	8337802
431.	COIL MAGNET 125 OHMS 74VDC	8339386
432.	RELAY AGASTAT	8349285
433.	CONTACTOR	8349386
434.	CONTACTOR	8355578
435.	COUPLING ADAPTER	8355584
436.	CONTACTOR	8357465
437.	RESISTOR 5 OHMS 25W ASSY	8357920
438.	RELAY	8361774-UC
439.	RELAY 6 POLE 10A	8361775
440.	PANEL ASSY	8362859
441.	RELAY	8364908
442.	FIELD CURRENT TRANSDUCTOR	8365307
443.	RELAY WITHOUT MOUNTING BRACKET	8370839
444.	HOUSING ASSY, STAT. CONTACT	8373349
445.	CARRIER ASSY MOVABLE CONTACT	8373351
446.	CONTACTOR, Motor field shuntin	8373478
447.	RELAY	8391256

448.	RELAY TIME DELAY	8392491
449.	IDAC PANEL	8397747
450.	KIT ASSY ARC CHUTE ROUND FRONT	8399841
451.	CONTACTOR 300A	8400143
452.	RELAY BC	8404532
453.	COIL 464 Ohms, Traction Motor	8406883
454.	ANGLE, Mounting - 1 x 1 x 10 I	8413530
455.	COIL Magnet 125 Ohms	8146877
456.	ROD ASSY PLUNGER	8152561
457.	PLATE, Magnet bottom	8152563
458.	VANE MOTOR	8163954
459.	COIL MAGNET 1100 Ohms 74 VDC	8184369
460.	COIL 355 Ohms	8188450
461.	PAD, Spacer 5/16 x 3/4 x 1-11/	8196063
462.	BASE ASSEMBLY, LOWER CONTACT	8209956
463.	CONTACTOR	8210242
464.	COIL MAGNET 495 Ohms 74 VDC	8258324
465.	BASE ASSEMBLY, Upper contact	8258614
466.	CONTACTOR, Shunt field	8265545
467.	TERMINAL SUPPORT	8271099
468.	TRANSDUCTOR	8273497
469.	CARRIER ASSY	8276115
470.	VANE MOTOR & COMMUTATOR ASM	8277229
471.	COIL Magnet 55.6 Ohms	8282039
472.	COIL MAGNET-400 Ohms-74 V.D.C.	8284682
473.	CHUTE ASSY., Arc	8285324
474.	CONTACT STAT. 4-1/4 x 3 x 2-13	8327310
475.	COUPLING	8361649
476.	RELAY	8363130
477.	CONTACTOR, Shunt field 24 VDC	8363270-24VDC
478.	CONTACTOR, FS, LTT	8365513
479.	CONTACTOR, FS, LTT	8365513-24VDC
480.	RELAY	8367084
481.	CONTACTOR, Shunt field	8371555
482.	YOKE, Magnet "U" type	8375503
483.	GEN. FIELD RELAY	8383145
484.	ARMATURE ASSEMBLY	8389449
485.	RELAY	8392855

486.	RELAY 6NO-8NC	8394594
487.	GENERAL PURPOSE RELAY	8398705
488.	RESISTOR 4.8 OHMS 400W 5%	8399938
489.	BASE ASSY. LOWER CONTACT	8409381
490.	BASE, Lower contact	8409382
491.	CARRIER ASSY, Aux. interlock	8409390
492.	BAR, Bus - Copper - 4" x 3/4"	8413527
493.	RECTIFIER	8416094
494.	RECTIFIER	8421017
495.	COIL 121 Ohms	8424707
496.	RELAY TIME DELAY	8427842
497.	SWITCH SNAP AUX. INTERLOCK	8429833
498.	RECTIFIER (CR-BC)	8416192
499.	TIMER UNIT, Pneumatic	8420242
500.	COIL JK 255 OHMS	8428573
501.	VOLTAGE LIMIT PANEL	8431594
502.	KIT ASSY, FLEX MAIN STATIONARY	8441835
503.	PIN 5/16 DIA x 1-59/64 LG	8446411
504.	WHEEL SLIP RELAY	8449756
505.	CONTACTOR POWER	8458535-28VDC
506.	SWITCH ASSY, Magnetic 24VDC	8464113-24VDC
507.	CORE, Magnet 1-3/4 OD x 5-9/64	8468833
508.	CONTACT ASSEMBLY, Pivot	8468836
509.	KIT ASSY, Supp bar & bottom	8468850
510.	KIT ASSY,	8471755
511.	CONTACTOR EPC 300A, 2NO - 2NC	8473355
512.	HOUSING ASSY, SIDE PLATE	8475611
513.	GENERAL PURPOSE RELAY	8357415
514.	CONTACTOR Motor field shunting	8358407
515.	PANEL ASSEMBLY	8361752
516.	RELAY	8361774
517.	GENERAL PURPOSE RELAY	8363168
518.	CONTACTOR, Shunt field	8363270
519.	RELAY	8367562
520.	COIL 550 OHMS	8373350
521.	PANEL	8377230
522.	PANEL ASSEMBLY, Rate control	8377273
523.	RESISTOR 2000 & 2000 OHMS 300W	8398604

524.	RELAY	8403578
525.	BOARD POUR DIODE MOUNTING	8406036
526.	COIL ASSY BLOWOUT	8407472
527.	CONTACTOR, Shunt field	8407837
528.	COIL 140 Ohms	8409385
529.	PANEL, FRONT 11 X 7-7/8 X 1/8	8413524
530.	CONTACTOR ST 1000 AMPS	8415485
531.	COIL 1128 Ohms	8415916
532.	COIL 1853 Ohms	8415919
533.	CONTACTOR, Starting auxiliary	8482180
534.	NEGATIVE BUS BAR	8485238
535.	CONTACT KIT, Main	8488949
536.	SUPPORT KIT, Moving contact	8492376
537.	DISK, ARMATURE	8801421G1
538.	SPRING w/plug armature tension	8823898G1
539.	CONTROLLER	9091052
540.	CARRIER ASSEMBLY	9093180
541.	CONTACTOR, Basic 4 Pole	9310498
542.	COIL/BRACKET KIT 542 OHMS	9517555
543.	INTERLOCK ASSY	9539484
544.	INTERLOCK ABCD EFGH	9539496
545.	INTERLOCK ASSY 3NO - 1NC	9539500HD
546.	INTERLOCK JKLM-NPQR	9539501
547.	SWITCH-LIMIT 2NO-2NC	9577662
548.	COIL 100 OHMS 74 VDC INT.	9577663
549.	COIL Magnet 41.1 OHMS - 48 VDC	9577663-48VDC
550.	COIL 21.1 Ohms	9956024G1
551.	COIL 82 / 84.9 OHMS	9960925G1
552.	COIL 1.03 Ohms	9960940G1
553.	COIL 23.5 Ohms	9960942G1
554.	COIL 189 OHMS et 0.318 OHMS	9960997G1
555.	SHUNT	9963468G1
556.	CONTACT	9963477G12
557.	COIL Reset 1250 Ohms	DLL 11-1519
558.	CONTACTOR ST 1000 AMPS	8433397
559.	COIL Magnet 80 OHMS	8435656-36VDC
560.	PLATE, Pole 2-3/16" x 1-3/4" x	8436614
561.	SHEET, Insulating	8436634

562.	RESISTOR 2K, 2K & 2K 160W	8444315
563.	CONTACTOR, Generator start	8445890
564.	KIT FAN COOLING	8446092
565.	SUPRESSOR ASSEMBLY	8452963
566.	ANGLE	8454215
567.	CONTACTOR POWER	8458534
568.	RELAY TIME DELAY	8461849
569.	SWITCH ASSY, Magnetic	8464113
570.	SWITCH ASSY, Magnetic	8464114
571.	SWITCH ASSY, Magnetic	8464116
572.	SWITCH ASSY, Magnetic	8464117
573.	COVER, Interlock contact	8475685
574.	CONTACTOR	8476047
575.	PIN, Roller	8476975
576.	PANEL ASSY	8481557
577.	SPACER	8482808
578.	HEAT SINK ALTERED	8485241
579.	BUS BAR POSITIVE 3/16 x 3/4 x	8485243
580.	CONTACT KIT, Stationary	8488951
581.	RELAY, TIME DELAY	8492028
582.	CONTACT KIT, Movable	8492373
583.	CONTACT	8800657G1
584.	ARCING HORN	8814851P1
585.	COIL 73 Ohms	8827086G1
586.	COIL 62.5 Ohms	8827098G1
587.	BRACKET 4 POS. NON-AJUST.	8831781P1
588.	ARMATURE ASSEMBLY	8839157G6
589.	HOUSING	8843512P1
590.	CONTACT KIT	8846836G2
591.	FINGER ASSY	8860205G1
592.	COIL 32.1 ohms	8860488G1
593.	BLOCK, Finger	8860689P1
594.	ARMATURE with finger block &	8860802G1
595.	KIT ASSY	9098726
596.	ADJUSTER RIGHT	9200189
597.	LOAD REGULATOR	9317181
598.	CONTACT KIT	9539202
599.	INTERLOCK	9539490



600.	INTERLOCK	9539498
601.	SUPPORT ASSY, Stat. contact	9577669
602.	CORE, Yoke	9577670
603.	COIL 0.167 Ohms	9956028G1
604.	COIL 1558 Ohms	9956034G1
605.	COIL 66.2 Ohms	9960906G1
606.	KIT, SENSOR INTERLOCK	DLL 99-1865
607.	CONTACTOR	8332847
608.	RELAY BC	8334925
609.	CONTACT MOVABLE NON ARCING	8337577
610.	COIL 19.8 Ohms	8339342-24V
611.	PANEL ASM SENSOR	8357383
612.	GENERAL PURPOSE RELAY	8357415-24VDC
613.	GENERAL PURPOSE RELAY	8357417
614.	COIL Magnet 267 Ohms	8358489
615.	GROUND RELAY	8361776
616.	RELAY	8364294
617.	CONTACTOR	8365514
618.	RELAY 5NO-3NC	8369154
619.	KIT OPERATING LEVER	8372056
620.	CARRIER ASSY MOVABLE CONTACT	8373365
621.	YOKE MAGNET "U" TYPE	8375504
622.	CIRCUIT BOARD	8378574
623.	COVER, Relay	8387477
624.	RECTIFIER ASSEMBLY	8416095
625.	TIMER UNIT PNEUMATIC	8420099
626.	RELAY	8421610
627.	RELAY 6 POLE 10A	8424310
628.	COIL MAGNET 120 Ohms	8424741
629.	COIL MAGNET 270 Ohms	8424741-125VDC
630.	COIL 3.1 OHMS - 12VDC	8424741-12VDC
631.	INTERLOCK ASSEMBLY	8424742
632.	SWITCH SNAP AUX. INTERLOCK	8429832
633.	CARRIER ASSEMBLY 3 contacts	8431415
634.	RECTIFIER ASSEMBLY	8433751
635.	POST ASSEMBLY, Contact	8435874
636.	BRACKET ASSEMBLY INCL.	8436627
637.	RELAY BC	8443212

638.	CONTACTOR, LTT	8451158
639.	INSULATOR	8451525
640.	RELAY	8451991
641.	KIT INTERLOCK ASSY,	8453018
642.	KIT ASSY., Support bar	8465933
643.	CONTACTOR	8419344
644.	RELAY	8421094
645.	COIL MAGNET 173 Ohms - 96VDC	8424741-96VDC
646.	COIL LM 205 OHMS + NP 47 OHMS	8428572
647.	CARRIER ASSEMBLY 2 contacts	8431417
648.	COIL Magnet 417 OHMS	8435656
649.	SPACER, Insulating	8436615
650.	POLE, Stationary magnet	8436618
651.	SPRING ASSY	8441836
652.	COIL Magnet 66.5 OHMS	8448524
653.	DIODE ASSEMBLY	8452962
654.	LOAD REGULATOR	8453918
655.	CARRIER ASSY, Aux. Interlock	8461485
656.	CONVERSION KIT	8465934
657.	CUTOUT ASSEMBLY, Traction moto	8468828
658.	DETENT ASSY, Interlock	8478299
659.	HOUSING ASSY	8488190
660.	RUNNER KIT, Arc	8488948
661.	CARRIER KIT, ABDE, NO - CF, NC	8491684
662.	TERMINAL KIT, Top	8492375
663.	COVER KIT, Switch	8492378
664.	CUTOUT KIT, Traction motor	8492383
665.	CONTACT	8800654G1
666.	CORE, Reset coil magnet	8801066
667.	PIN	8817579P1
668.	PLATE C.E.	8819127P1
669.	SUPPORT O BRAS	8831782P1
670.	ARMATURE	8834202G1
671.	ARC CHUTE	8834209G1
672.	BLOWOUT COIL ASSY	8852404G5
673.	COIL 467 Ohms	8860474G1
674.	FRONT MOUNTING PLATE ASM	9092106
675.	PIN, Hinge	9093152

676.	ADJUSTER LEFT	92001810
677.	GENERAL PURPOSE RELAY	9312343
678.	CONTACTOR ST 2000 AMPS	9315518
679.	IRON KIT, Hold on	9500387
680.	INTERLOCK 2NO-2NC	9539494HD
681.	CONTACTOR	9559825
682.	CONTROLLER MECHANISM DYNAMIC	9563449
683.	CARRIER ASSY Movable contact	9577656
684.	LIMIT SWITCH - SERIE A	9577690
685.	COIL 33 Ohms	9960973G1
686.	HORN	9963437G1
687.	KIT SPRING 1 - ARMATURE ASSY	DLL 99-1883
688.	KIT SPRING 2 - FRAME	DLL 99-1884
689.	KIT RED CARD	KIT4001B
690.	CONTACTOR CONVERSION	8465932
691.	BEARING, Shaft 3/16 x 2-39/64	8468810
692.	YOKE, Magnet	8468839
693.	ROLLER	8476976
694.	RHEOSTAT	8477210
695.	ROLLER ASSY., Interlock - Dyna	8478252
696.	INDICATOR SELECTOR	8480043
697.	INDICATOR ASSY-THROTTLE	8480044
698.	INTERLOCK KIT, Auxiliary	8488946
699.	COIL KIT, Blowout	8488954
700.	MAGNET KIT, Blowout	8488956
701.	CONTACT KIT, Stationary	8492374
702.	ARMATURE ASSY W/BLOCK	8839157G1
703.	CAM BLOCK ASSY 8 POS	8846291G1
704.	COIL 16.8 Ohms	8860431G1
705.	COIL Operating + Series	8860486
706.	CONTROLLER MECHANISM DYNAMIC	9093629
707.	CONTACTOR, Basic 2 Pole	9310496
708.	CONTACTOR, Basic 3 Pole	9310497
709.	RECTIFIER PANEL	9316438
710.	RHEOSTAT - OHMITE STYLE	9322456
711.	CONTACTOR 2000A 2NO-2NC	9325207
712.	CONTACTOR 2000A 2NO-2NC	9325207
713.	COIL 34 Ohms	9523041

714.	INTERLOCK ASSY	9539486
715.	INTERLOCK 2NO-2NC	9539491
716.	BUS BAR	9559972
717.	CHUTE, Arc - High cap	9577680
718.	COIL 1558 Ohms	9956034
719.	COIL 182 Ohms	9960965G1
720.	COIL 1075 Ohms	9960971G1
721.	COIL 49.4 OHMS et 37.2 OHMS	9960975G1
722.	SWITCH SNAP AUX. INTERLOCK	DLL 08-2017
723.	Diode Negative	E40029131
724.	Diode Positive	E40029132
725.	Diode Boot AR10	E8378316
726.	Diode Socket	E8361524
727.	Diode Positive AR20	E40032602
728.	Diode Negative AR20	E40032603
729.	Diode Boot AR20	E40048214
730.	Spring Clip AR10	E8434285
731.	Spring Clip D14	E8434286
732.	Spring Clip TA17	E40132923
733.	Rectifier Bank 2000v	E9084995
734.	Brushholder D14	E8413188
735.	Brushholder TA17	E8413189
736.	Glass Oval AR10 6" x 12.13/16"	E8167423
737.	Weather-stripping	E8489788
738.	Glass Inspection Air Box	E8345780
739.	Glass Diode Inspection	E8433679
740.	Weather-stripping	E8167425
741.	Filler	E8169637
742.	Brushholder Clip U Shape	E8330890
743.	Slip Ring Assembly	E8345866
744.	AR 10 Closure	E8390572
745.	EMD Alternator	AR10
746.	EMD Alternator	AR11
747.	EMD Alternator	AR15
748.	EMD Alternator	AR16
749.	EMD Alternator	Ar17
750.	EMD Alternator	Ar20
751.	EMD Alternator	TA17

752.	GE Alternator	GTA11	
753.	GE Alternator	GTA24	